ECU Upgrade [ECI Connection Guide]



Contents

- 1. Overview
- 2. Components
- 3. Connection Between Components
- 4. Initial Ethernet Setup

1. Overview

This document guides the procedure needed for ECU upgrades using Ethernet communication, specifically for connecting GDS M/KDS with ECI. (One-time setup required for the initial connection between GDS-M and ECI)

- 2. Components
 - A. 1 x ECI (Ethernet Communication Interface)



B. 1 x 5-pin cable, 1 x C-type cable



C. 1 set of GDS M/KDS equipment



- 3. Connection Between Components
 - A. Method of Connection
 - i. Connecting between GDS M/KDS and the cable

Connect the cable (5-pin or C-type) to the tablet using the USB port that matches the cable.



ii. Connecting Cable and ECIConnect the cable to the ECI by aligning the arrows on the cable and ECI.



iii. Connecting VCI II, ECI Connect the VCI II to the ECI.



iv. Connecting ECI, Vehicle
Connect the ECI cable to the vehicle's OBD port.
(It doesn't matter if the vehicle does not require
Ethernet communication. Only the power supply
to the ECI is necessary.)



B. Schematic of ECI Connection





- 4. Initial Tablet IP Setup for Ethernet Communication
 - A. Connecting the Equipment to the Vehicle

Connect the GDS-M to the vehicle's OBD port as shown in the diagram below.



B. Setting the Tablet's Ethernet IP

 Go to Settings > Connections > Select Ethernet > Ethernet device configuration

	< More connection setting:	5		< Ethernet
A software	Nearby device scanning		A software update is availa	Ethernet Concernent
update is availa	Printing		Later Update	Configure Ethernet device
Q	VPN None		Q	Am
offie - Apps and features	Private DNS Enabled Ethernet		Samsung account Profile - Apps and features	$\left\langle \right\rangle$
Connections mi-fi - Bluetoots - Aliptane mode	h		Connections W/FL - Illusionth - Applane mode	1
Connected devices Quick Share - DeX mode		9	Connected devices Ourick Share - Dex mode	
Modes and Routines Modes - Routines) {		Modes and Routines	
Sounds and vibration Sound mode - Ringtone			Sounds and vibration Sound mode - Hingtone	
Notifications Status har + Do rel distarb			Status ber - Do not disturbe	
Display Begisteess + Eye constant shield + Nonigation bar			Display Display Another the comfort sheld - Nerigation bar	
Wallpaper and style Wallpapers - Color patette			Wallpaper and style Wallpapers + Color particle	
Home screen Layout + App Ican badges			Home screen Layout - Ado scon badges	
Lock screen			Lock screen	

(The screen layout may differ depending on the Android OS version of the tablet. It could be Settings > More Connection Settings > Ethernet)
If the Ethernet option is disabled despite the

vehicle OBD port and the ECI OBD cable being correctly connected (VCI-II green LED is on), check if reattaching the ECI USB cable to the tablet's USB port enables it.

- C. IP Settings
 - i. Ethernet Device Configuration > Static IP

A software	< Ethernet	100	А	softw	are	< E	thernet			
pdate is availa	Connactite Ethemat national.		upda	ate is a	vaila		ct Ethernel	device		
Later Update	Configure Ethernet device			Later Up		eth				-
						Cor	nection typ	0		
Q					c	χ Ο	DHCP			
amsung account			Samsur Profile - Ap	ng accourt os and features	nt 🖪) IP a	Static IP ddress			٦
						- I	mask			-
Connections wifit - Blancoll - Alloface mede				nections + Elaersolt + :	Septem reado	Nem	nask			
Connected devices			Con	nected devic	D 5	DNS	6 acidress			
Duitk Share + DeX mode				Share - DeX a			addreta			
							ault gatewa	¥		
Modes and Routines: Modes - Restricts				es and Rout s + Foutines	ines	Pro	sit gateway K V			-
Sounds and vibration Sound mode - Regions				nds and vibra		Nor	S			-Y
Notifications Status bar + Do not distub				fications	latura -		Discar	d	Save	
	Select Ethernet device eth0		(Q)	٥		0	(12)		۲	*
Display Bightess - Eye constant salest +	Connection type									
	OHCP				1	2	3	×		
Navigation ber					4	5	б	Next		
Wallpaper and style Walpapers - Chen palatin	Static B									
Norganist bar	Static B Proxy None				7	8	9			

ii. Enter the Static IP and Save

Static IP Address for Reference					
IP	10.0.128.0				
Netmask	255.0.0.0				
DNS address	8.8.8.8				
Default router	10.0.128.0				