


System Identification

It shows specification information of the controller (part number, H/W, S/W, etc.) mounted on the vehicle.



Basic Operation

When entering into a function, it searches specification information of the selected controller.

Re-search/Stop

You can stop search function through 'Stop' button at the bottom. You can re-search it through 'Re-search' button at the right side of the controller.

