





# **Recorded Data**

You can view the data saved in tablet PC, and also copy the driving data saved in VCI II.



## **Basic Operation**

The user can view, share or delete the data saved in tablet PC based on the user's need.



## **Open Files**

### Saved Data File (.GSR)

You can check the data in Text Mode and Graph Mode.



⟨Text Mode⟩






⟨Graph Mode⟩

### **Image Files**

You can check the image files that are saved.






+	Maximize/minimize
	View one image page
	View multiple image pages (maximum of 4 pages)
<u>~</u>	Detailed information of images
	Print

## Sharing, Export and Delete


#### Sharing

You can share the data by using various methods supported by your tablet.




#### Export

You can export the data through an external saving device.



Delete

You can delete the data via Delete button.



# **Data Copy**

You can copy and paste the data files saved in VCI to your tablet PC. Select a data to copy, and touch 'Data Copy' button.

\* It is saved in the file path of NvciData/Record of internal storage device.

